


# MODEL KRN45

**SPOTNAILS®**  
DIVISION OF PEACE INDUSTRIES, LTD.  
1100 Hicks Rd  
Rolling Meadows, IL 60008  
Phone: 847-259-1620



## MODEL KRN45

Ref. No.	Part No.	Description
1	P-24359	Hex Soc. Head Bolt
4A	AS-60048	Cap Assembly
5	P-53131	Upper Body Guard
6	P-62057	Gasket
7	P-15144	Piston Stopper
8	P-18255	Spring
9	P-64259	O-Ring
10A	P-66093	Head Valve
11	P-64270	O-Ring
13	P-32160	Retaining Ring
14	P-64271	O-Ring
15	P-64272	O-Ring
16	P-05080	Cylinder Spacer
17	P-64273	O-Ring
19A	AS-66120	Driver Assembly
20	P-05082	Cylinder
21	P-64274	Cylinder Ring
22	P-15145	Bumper
23	P-15146	Driver Guide
24	P-01250	Body
25	P-62058	Gasket
26	P-60145	End Cap
28	P-24360	Hex. Soc Head Bolt
29	P-64275	O-Ring
30	P-64276	O-Ring
31	P-22125	Valve
32	P-64277	O-Ring
33	P-64278	O-Ring
34	P-64279	O-Ring
35	P-22126	Valve Plunger
36	P-64280	O-Ring

Ref. No.	Part No.	Description
37	P-18256	Spring
38	P-22127	Plunger
39	P-64281	O-Ring
40	P-60146	Plunger Cap
42A	AS-21007	Trigger Assembly
43	P-07262	Spring Pin
45	P-15137	Guide Safety Lever
46	P-62059	Gasket
47	P-08445	Wear Plate
48	P-53132	Lower Body Guard
49	P-24361	Hex. Soc. Head Bolt
50	P-18262	Spring Safety
51A	AS-53038	Upper Safety Lever Assembly
53	P-26134	Locknut
55A	AS-53039	Safety Nose Assembly
57	P-64282	O-Ring Feed Piston
58	P-66094	Feed Piston
59	P-18263	Feed Spring
60	P-18264	Feed Spring
61	AS-18007	Spring Guide
62	P-12362	Feed Piston Cover
63	P-24363	Hex Soc. Head Bolt
64	P-18265	Feed Pawl Spring
65	P-07267	Feed Pawl Shift
66	P-09163	Feed Pawl
67	P-18266	Spring Lock Shaft
68	P-07268	Lock Shaft
69	P-04054	Nail Guide Latch
70	P-07269	Spring Pin
71	P-96078	Nail Guide
72	P-96079	Nail Stopper

Ref. No.	Part No.	Description
73	P-18267	Spring Nail Stopper
74	P-12363	Nail Guide Cover
75	P-96080	Bushing
76	P-24371	Hex. Soc. Head Bolt
77	P-64283	O-Ring
78	P-07270	Nail Guide Pin
79	P-07271	Shaft Magazine Cover
80	P-12364	Magazine Cover
81	P-96081	Tension Post Bushing
82	P-96082	Nail Holder
83	P-96083	Adjust Post
84	P-18268	Nail Holder Spring
85	P-12365	Magazine
86	P-96084	Bushing Magazine
87	P-32167	Flat Washer
88	P-96085	Magazine Guide
89	P-24372	Screw
90	P-96086	Tension Post Bushing
91	P-26138	Adjusting Nut
92	P-13050	Gauge Bracket
93	P-96087	Shingle Guide
94	P-24373	Hex. Soc. Head Bolt
95	P-24375	Hex. Soc. Head Bolt
96	P-32161	Flat Washer
97	P-12366	Safety Cover
98	P-96088	Bushing
99	P-24374	Hex Soc. Head Bolt
100	P-96089	Debris Shield
101	P-96090	Button
102	AS-12152	Complete Magazine Assembly
103	P-32175	Lock Washer

◆ Included in Magazine Assembly