


MODEL WS4840-W4

SPOTNAILS®

DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd
Rolling Meadows, IL 60008
Phone : 847-259-1620



4/27/09

SPOTNAILS MODEL WS4840-W4

Ref No.	Part No.	Description
01	P-24370	Screw
02	P-96118	Bushing
03	P-70042	Exhaust Deflector
04	P-64377	O-Ring
05	P-32217	Washer
06	P-24300	Screw
07	P-32211	Flat Washer
08	P-60174	Cap
◆	09	P-15193 Exhaust Seal
◆	10	P-64384 O-Ring
11	P-18331	Poppet Spring
◆	12	P-64385 Poppet O-Ring
13	P-63038	Poppet
◆	14	P-64233 Piston Stop O-Ring
◆	15	P-64386 Cylinder Seal O-Ring
16	P-03070	Guide Spacer
◆	17	P-62071 Gasket
18	P-05097	Cylinder
◆	19	P-64387 Cylinder O-Ring
◆	20	P-64242 O-Ring
◆	21	P-64388 Piston O-Ring
22	AS-06058	Piston & Driver Assembly

Ref No.	Part No.	Description
23	P-15195	Bumper
24	P-01273	Body
25	P-64389	O-Ring
26	P-60175	End Cap
27	P-15196	Return Seal
28	P-08501	Wear Plate
29	P-26125	Nut
30	P-24456	Screw
31	P-24307	Screw
32	P-24311	Screw
33	P-07290	Roll Pin
34	P-10326	Front Plate
35	AS-99097	1/2" Robina Flooring Assy.
37	P-07291	Pin
38	P-53165	Safety Guide
39	P-18328	Spring
40	AS-53074	Safety Assembly
41	P-64240	O-Ring
42	P-07327	Trigger Pin
43	AS-21008	Trigger Assembly
44	P-15194	Valve Seal

Ref No.	Part No.	Description
45	P-18283	Spring
46	P-64390	O-Ring
47	P-22165	Plunger
48	P-22166	Valve Housing
49	P-64391	O-Ring
50	P-24309	Screw
51	P-12232	Track Cover
52	P-18233	Spring Clip
53	P-18232	Negator Spring
54	P-12231	Track
55	P-26124	Nut
56	P-32144	Washer
57	P-13081	Bracket
58	P-24306	Screw
59	P-03053	Spacer
60	P-24310	Screw
61	P-24319	Screw
62	P-09149	Pusher
63	P-06240	Driver Blade
64	P-07363	Safety Pin
65	AS-21021	Restrictive Trigger
66	P-18267	Spring

◆ Parts Included In AS-97281 O-Ring And Seal Kit