


MODEL XS3640-A

SPOTNAILS[®]

DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd
 Rolling Meadows, IL 60008
 Phone : 847-259-1620

SPOTNAILS MODEL XS3640-A



2015/5/6

Ref No.	Part No.	Description	Ref No.	Part No.	Description
01	P-24370	Screw	37	AS-53981	Safety Assembly
02	P-96118	Bushing	38	P-64332	Valve Housing O-Ring
03	P-70041	Exhaust Deflector	39	P-22144	Trigger Valve Cap
04	P-64377	O-Ring	40	P-64333	O-Ring
05	P-24300	Cap Screw	41	P-64334	O-Ring
06	P-32211	Flat Washer	42	P-64335	O-Ring
07	P-60172	Cap	43	P-22145	Pilot Valve
08	P-15187	Exhaust Seal	44	P-64336	O-Ring
09	P-64378	O-Ring	45	P-18227	Spring
10	P-18327	Poppet Spring	46	P-64383	Plunger O-Rings
11	P-64028	Poppet O-Ring	47	AS-22037	Plunger Assembly
12	P-63037	Poppet	49	P-64328	O-Ring
13	P-64379	Piston Stop o-Ring	50	P-64240	O-Ring
14	P-64380	Cylinder Seal O-Ring	51	P-07327	Trigger Pin
15	P-03079	Guide Spacer	52	AS-21008	Trigger Assembly
16	P-62070	Gasket	53	P-26126	Nut
17	P-64228	Piston O-Ring	54	P-24430	Screw
18	AS-06044	Piston & Driver Assembly	55	P-24432	Screw
19	P-64330	Cylinder O-Ring	56	P-12417	Magazine Cover
20	P-05096	Cylinder	57	P-07340	Negator Spring Pin
21	P-64419	O-Ring	58	P-18334	Negator Spring
22	P-15197	Bumper	59	P-13070	Bracket
23	P-01263	Body	60	P-24301	Screw
24	P-64312	O-Ring	61	P-26159	Nut Plate
25	P-60156	End Cap	62	P-24433	Screw
26	P-07262	Pin	63	P-24434	Screw
27	P-15203	Return Seal	65	P-12416	Magazine
28	P-24358	Screw	66	P-07339	Pin
29	P-10285	Stationary Front Plate	67	P-53167	Latching Safety (optional)
30	P-07357	Pin	69	P-97454	Filter(Optional)
31	P-10289	Removable Front Plate	70	P-32107	Washer
32	P-18333	Latch Spring	71	AS-97296	String Guide Assembly (Optional)
33	P-08521	Wear Plate	72	P-53175	Roofing Safety (Optional)
34	P-04062	Quick Clear Latch	74	P-09213	Pusher
35	P-53165	Safety Guide	75	AS-99088	Wear Plate Filler
36	P-18328	Spring	76	AS-21026	Restrictive Trigger Assy. (Optional)
	◆	Parts Included In AS-97288 O-Ring & Seal Kit			