


MODEL CB1850

SPOTNAILS®
 DIVISION OF PEACE INDUSTRIES, LTD.
 1100 Hicks Rd
 Rolling Meadows, IL 60008
 Phone : 847-259-1620

SPOTNAILS MODEL CB1850



Ref No.	Part No.	Description	Ref No.	Part No.	Description
01	P-70043	Exhaust Deflector	36	P-64436	O-Ring
02	P-64392	O-Ring	37	AS-04041	Latch Assembly
03	P-60192	Cap	38	P-64239	Valve Housing O-Ring
04	P-24300	Screw	39	P-22168	Upper Valve Housing
05	P-15199	Exhaust Seal	40	P-18336	Spring
06	P-64332	O-Ring	41	P-64240	O-Ring
07	P-22167	Poppet Valve Guide	42	P-22169	Plunger
08	P-64393	O-Ring	43	P-64421	O-Ring
09	P-62072	Gasket	44	P-22170	Lower Valve Housing
10	P-18226	Spring	45	P-64241	O-Ring
11	P-64232	Poppet O-Ring	46	P-18337	Spring
12	P-63039	Poppet Valve	47	AS-21017	Sequential Trigger Assy.
13	P-64233	Piston Stop O-Ring	48	P-07234	Trigger Pin
14	P-64234	Cylinder Seal O-Ring	49	AS-21006	Bump Fire Trigger Assembly
15	P-03071	Retaining Ring	50	P-26126	Nut
16	P-64394	O-Ring	51	P-24450	Screw
17	P-03072	Cylinder Spacer	52	P-32211	Washer
18	P-64616	O-Ring	53	P-13098	Bracket
19	P-05113	Cylinder	54	P-24364	Screw
20	P-64395	O-Ring	55	P-32144	Washer
21	P-64236	Piston O-Ring	56	P-24317	Screw
22	AS-06076	Piston & Driver Assembly	57	P-04081	Latch
23	P-15121	Bumper	58	P-12483	Magazine
24	P-15124	Return Seal	59	P-09214	Pusher
25	P-01264	Body	60	P-18483	Spring Stem
26	P-26165	Nut	61	P-18484	Spring
27	P-64389	O-Ring	62	P-12484	Magazine Cover
28	P-60175	End Cap	63	P-07237	Pin
29	P-18588	Spring	64	P-18485	Spring
30	P-07508	Step Pin	65	P-04082	Latch Housing
31	P-53184	Safety	66	P-32227	Washer
32	P-08494	Wear Plate	67	P-24304	Screw
33	AS-10055	Front Plate Assembly	68	P-07234	Pin
34	P-07356	Pin	69	P-15270	Return Seal
35	P-07354	Pin	70	P-24511	Screw-2

◆ Parts Included In AS-97320 O-Ring And Seal Kit