


# SPOTNAILS®

DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd  
 Rolling Meadows, IL 60008  
 Phone : 847-259-1620

## MODEL LCS6838



### SPOTNAILS MODEL LCS6838

Ref No.	Part No.	Description	Ref No.	Part No.	Description
01	P-24370	Screw	48	P-64378	O-Ring
02	P-96118	Washer	49	P-18497	Spring
03	P-70046	Exhaust Deflector	50	P-15240	Piston Stop
04	P-64377	O-Ring	51	P-12506	Feed Piston Cover
05	P-32217	Washer	52	P-32243	Retaining Ring
06	P-24523	Cap Screw(4)	53	P-64579	O-Ring
07	P-32242	Flat Washer(4)	54	P-18498	Hold Down Spring
08	P-60218	Cap	55	P-13104	Feed Chute
09	P-15219	Exhaust Seal	56	P-26144	Lock Nut
10	P-64384	O-Ring	57	P-24518	Screw(2)
11	P-18331	Poppet Spring	58	P-24353	Screw(5)
12	P-64232	Poppet O-Ring	59	P-12507	Magazine Right
13	P-63042	Poppet	60	P-12509	Magazine Cover
14	P-64422	Piston Stop O-Ring	61	P-12508	Magazine Left
15	P-64467	Cylinder Seal O-Ring	62	P-24516	Screw(2)
16	P-03081	Guide Spacer	63	P-26143	Nut
17	P-05106	Cylinder	64	P-18233	Spring Clip
18	P-64235	Cylinder O-Ring	65	P-18232	Negator Spring
19	P-64423	Cylinder O-Ring	66	P-20035	Negator Spring Drum
20	P-64424	Piston O-Ring	67	P-24307	Screw(5)
21	AS-06104	Piston & Driver Assembly	68	P-10293	Static Front Plate
22	P-15121	Bumper	69	P-64434	O-Ring
23	P-15161	Return Seal	70	P-07356	Step Pin
24	P-62092	Gasket	71	AS-04037	Latch Assembly
25	P-01298	Body	72	P-10292	Removable Front Plate
26	P-64240	O-Ring(2)	73	P-07239	Pin
27	P-30096	Barb Fitting(2)	74	P-08484	Wear Plate
28	P-53165	Safety Guide	75	P-07262	Pin
29	P-18328	Spring	76	P-13122	Feed Chute Bracket
30	P-52037	Safety	77	P-24304	Screw
31	AS-53076	Safety Assembly	78	P-12571	Magazine Cover
32	P-32244	Washer	79	P-16024	Cover Rod
33	P-97481	Belt Clip	80	P-12572	Magazine
34	P-07327	Trigger Pin	81	P-18463	Spring
35	P-07262	Pin	82	P-97464	Button
36	P-64239	O-Ring(2)	83	P-97466	Housing
37	P-22114	Bleeder Valve	84	P-18454	Spring
38	P-64241	O-Ring	85	P-05107	Fixed Spacer
39	P-18227	Spring	86	P-97463	Plug
40	P-22179	Plunger	87	P-18462	Spring
41	AS-21022	Trigger Assembly	88	P-09242	Pusher
42	P-97488	Tubing	89	P-03085	Spacer
43	P-07395	Pin	90	P-13123	Bracket
44	P-97489	Cap Feeder	91	P-32170	Washer
45	P-18560	Spring	92	P-24517	Screw
46	P-05118	Feed Cylinder	93	P-15214	Return Seal
47	P-66115	Feed Piston			

◆ Parts Included In AS-97384 O-Ring and Seal Kit