

MODEL XBA1564

THIS TOOL EQUIPPED WITH
A RESTRICTIVE TRIGGER


SPOTNAILS[®]

DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd

Rolling Meadows, IL 60008

Phone : 847-259-1620



SPOTNAILS MODEL XBA1564

Ref No.	Part No.	Description
1	P-24370	Screw
2	P-96118	Bushing
3	P-70041	Exhaust Deflector
4	P-64377	O-Ring
5	P-24456	Cap Screw
6	P-32211	Flat Washer
7	P-60172	Cap
8	P-15187	Exhaust Seal
9	P-64378	O-Ring
10	P-18327	Poppet Spring
11	P-64028	Poppet O-Ring
12	P-63037	Poppet
13	P-64379	Piston Stop O-Ring
14	P-64380	Cylinder Seal O-Ring
15	P-03079	Guide Spacer
16	P-62070	Gasket
17	P-03073	Body Spacer
18	P-64228	Piston O-Ring
19	AS-06046	Piston & Driver Assembly
20	P-64330	Cylinder O-Ring
21	P-05105	Cylinder
22	P-64419	O-Ring
23	P-15188	Bumper
24	P-01267	Body
25	P-64312	O-Ring
26	P-60156	End Cap
27	P-15201	Return Seal
28	P-07262	Pin
29	P-53165	Safety Guide
30	P-18328	Spring
31	AS-53048	Safety Assembly
32	P-03074	Spacer
33	P-53170	Lower Safety
34	P-26125	Nut
35	P-08473	Wear Plate
36	P-18339	Spring

Ref No.	Part No.	Description
37	AS-10048	Front Plate Assembly
38	P-24358	Screw
39	P-07327	Trigger Pin
40	P-64240	O-Ring
41	AS-21008	Trigger Assembly
42	P-64328	O-Ring
44	AS-22037	Plunger Assembly
45	P-64383	Plunger O-Rings
46	P-18227	Spring
47	P-64336	O-Ring
48	P-22145	Pilot Valve
49	P-64335	O-Ring
50	P-64334	O-Ring
51	P-64333	O-Ring
52	P-22144	Trigger Valve Cap
53	P-64332	Valve Housing O-Ring
54	P-24300	Screw
55	P-24433	Screw
56	P-32170	Washer
57	P-13074	Bracket
58	P-26142	Nut
59	P-24353	Screw
60	P-12418	Magazine Cover
61	P-12419	Magazine
62	P-27182	Wear Insert
63	AS-09049	Pusher Assembly
64	P-18478	Negator Spring
65	P-18338	Spring Retainer
66	P-97454	Filter (Optional)
67	P-06232	Driver Blade
68	AS-21026	Restrictive Trigger
69	P-18267	Spring
70	AS-04040	Latch Assembly
71	P-07297	Pin
72	P-18482	Spring
73	P-24490	Sholder Screw

◆ Parts Included in AS-97286 O-Ring and Seal Kit